



# How to Clean Mikodam Panels

Mikodam panels do not require any special products to be cleaned. You can treat them as you would with other wooden furniture.

## Equipment:

Microfiber Duster

Microfiber & Cotton Cloths

Bucket or Spray Bottle

Fresh Water

Mask & Gloves

Cotton Swab (optional)


Furniture Cleaner (optional)



To clean the panels, you can use a microfiber duster instead of feathered ones. Microfiber dusters hold on to the dust particles instead of scattering them back into the air around the panels. Gently go over the panels with the duster making sure that you wipe over all surfaces.




For deeper cleaning use a damp cleaning cloth. Do not use any chemicals or bleaching agents, use fresh and clean water only. For the best results prefer a microfiber cloth. Either fill a bucket with clean water, dip the cloth in to dampen it and squeeze out any excess water before cleaning the panels or spray clean water onto the cloth with a spray bottle. Gently wipe the surfaces, then go over with a dry towel. You can prefer a cotton cloth for drying. Show extra care not to leave the surfaces wet.



When necessary, you can use liquid furniture cleaners following the instructions provided on the label. Keep in mind that such products might cause the surfaces to shine.

How dusty or oily the environment is will affect how often you need to service the panels. Under normal conditions, it is sufficient to clean the panels once every few weeks.





The form of each 3D panel requires different wiping methods however the overall logic is to gently reach all accessible points. Wipe the wooden panels in the same direction as the veneers. Do not apply too much pressure. You can use corners of the cloth to gently wipe the perforations or any openings if dust has settled in them. For any cases that might require extra attention, cotton swabs can be used.



#### **Beware not to:**

- X** use any hard chemicals
- X** use sponges, clothes, or any materials that might scratch the surfaces
- X** dampen any spots with electrical applications
- X** let the panels come into contact with too hot or too cold materials

If any food, beverage, or liquid of any kind spills onto the panels quickly dry the panel with a towel. Then wipe with a damp cloth, then go over with a dry cloth. In cases where the substance leaks into the panels (for instance through the perforations) consult a Mikodam specialist. The panels can be disassembled and reassembled if necessary, however for the durability of the panels this would not be recommended.



Solid wood Mikodam products, such as the HAZA line, are finished with a coating of protective oil. The oil both protects the surface and gives it color. It is natural for the oil to be absorbed over time. Also, the cleaning products used on these surfaces might remove some of the oil. When necessary, protective oils can be reapplied onto the solid wood products. Substitute oils, such as a hardwood floor oil, commonly found in markets, can be used.



The oils Mikodam uses follow the EN 13501-1: EN ISO 11925-2 and EN ISO 9239-1 standards and are Bfl-s 1 certified. They are composed of non-toxic elements; they do not contain solvents, water or Volatile Organic Compounds (VOC 0%). The oils are flammability-resistant. They are S1 compatible and have the least smoke emission feature.

### To apply:

Follow the instructions and recommendations on the box of the oil you buy.

Using a microfiber cloth apply thinly and evenly onto all parts of the Mikodam piece.

Leave to dry and repeat if necessary.

! Beware that using oils change the color and the finish of the wood. The instructions on the product usually include how that specific oil will affect the finish.

For best results, seek professional assistance.



When cleaning the panels hung high or mounted on the ceiling use a ladder (with caution) to reach the panels. Use the same advised cleaning tools and techniques. Be sure that the panels are fully secured during installation according to the Mikodam guidelines. When using a ladder preferably have someone accompany you.



Mikodam offers a 5-year warranty as protection against faulty goods. The warranty does not cover user errors.

